


Ledvion

POWERPLUGS

For Smart WiFi + Bluetooth lights



5692 DH Son en Breugel
Ekkersrijt 4304
The Netherlands
www.ledvion.com

Frequency range: 2.402 - 2.480GHz
Antenna gain: -1.0dbi
Max. radio transmission power: 16dBm

LVW10006 & LVW10007

EN GETTING STARTED

Set up in 4 easy steps

Before you start write down your network name & password. Note: this item only works on a 2.4GHz Wifi network, not on a 5GHz Wifi network. Please consult your router manual for settings.

1. Download the Smartlife app from the Google Play store, the Apple Store or scan the QR code with your camera.
2. Open the app. If using for the first time follow the on-screen instructions to create your account. To add this device start by touching 'add device' (+) and follow the on-screen instructions.



3. Turn the device on. The light bulb will start flashing. (If the light bulb or device does not start flashing, switch it on and off 3 times. This will reset the light bulb or device.)
4. Follow the on screen prompts to finish installation.


If you get the notification the product only works on 2.4GHz networks you should change the WiFi-frequency of your network to 2.4GHz only in the settings menu of your router.

NL AAN DE SLAG

Instellen in 4 eenvoudige stappen

Schrijft voordat u begint uw netwerknnaam en wachtwoord op. Opmerking: Dit item werkt alleen op 2.4 GHz wifi-netwerk, niet op een 5 GHz WiFi-netwerk. Raadpleeg de handleiding van uw router voor de instellingen.

1. Download de Smartlife app van de Google Play Store, Apple Store of scan de QR code van het product met uw camera.
2. Open de app. Gebruikt u de app voor de eerste keer. Volg dan de instructies op het scherm om uw account aan te maken. Om dit apparaat toe te voegen, begint u door 'apparaat toevoegen' (+) aan te raken en volgt u de instructies op het scherm.



3. Schakel de verlichting in. De lamp begint te knipperen. (Als de lamp of het apparaat niet begint te knipperen, schakelt u het driemaal in en uit. Hiermee wordt de lamp of het apparaat gereset).
4. Volg de aanwijzingen op het scherm om de installatie te voltooien.

Als u de melding krijgt dat het product alleen op 2.4 GHz-netwerken werkt, moet u de WiFi-frequentie van uw netwerk naar 2.4GHz wijzigen in het instellingenmenu van uw router.

